


First Floor

SCALE: 1/4" = 1'
(1:48)


The ruler above should measure 1". To print to correct scale set Adobe Reader's Page Scaling: option to "None"



Second Floor

SCALE: 1/4" = 1'
(1:48)

The ruler above should measure 1". To print to correct scale set Adobe Reader's Page Scaling: option to "None"



Third Floor

SCALE: 1/4" = 1'
(1:48)

The ruler above should measure 1". To print to correct scale set Adobe Reader's Page Scaling: option to "None"